


SunRunner

Front-Cut Riding Mower

Gear Drive



8 HP FRONT-CUT, 5 SPEED MOWER

MFG. NO. 1691330

MFG. NO. 1691457

12 HP FRONT-CUT 5 SPEED MOWER

MFG. NO. 1691198

MFG. NO. 1691458

42" MOWER

MFG. NO. 1691199

36" MOWER

MFG. NO. 1691332

TP-1105-03
882

Simplicity

Product Identification:

When ordering parts, keep your products serial number and manufacturer's number in mind. Variations may occur in a part between early and later model products, causing the product serial number to be listed in the parts description whenever these variations occur.

Record your I.D. numbers here for quick, future reference.

Product Mfg. No. _____ S/N _____ Mower Mfg. No. _____ S/N _____

Attention:

Standard torques appear in a chart at the end of the manual, while important individual torques are given on specific parts drawings.

CRITICAL and **MAJOR** notations point out important facts or instructions which relate to personal safety and proper machine operation. Any **CRITICAL** notation  which may appear in this book, pinpoints characteristics which, if not properly followed, can create a safety hazard. Any **MAJOR** notation  which may appear in this book, marks characteristics which, if not properly followed, may result in operating failure, shortened product life, or greatly reduced quality of the unit.

For your convenience, assembly notes are included in parts drawings to assist in repair and assembly of unit.

NOTE: Specifications may change without notice.

SIMPLICITY PRODUCTS FOR THE PROPER CARE OF EQUIPMENT

These genuine Simplicity products will help the owner extend the life of his equipment.

OILS - SPECIFICALLY BLENDED OF HIGH QUALITY BASE OILS & ADDITIVES.

Special Worm Gear (Reticul) Oil for use in all tillers and snowthrowers with worm gear auger drive. Required for protection of brass gears and mating parts. Case of 12 Quarts, Part #1685100, Individual Quarts #18065.

Multi-Purpose Hydraulic/Transmission Oil for use in most hydraulic applications, and hydrostatic and gear transmissions. Specific Simplicity applications: All hydrostatic transmissions, all bevel gear cases, all Broadmoor, Landlord, Sovereign, 4000, 6000, 7000 transmissions (except Peerless Gear Transmissions). (Not used in SunStar tractor transmission.) Case of 12 Quarts, Part #1685516, 2½ Gallon Container, Part #1685539.

2-Cycle Engine Oil, a premium lubricant for all 2-cycle air-cooled engines. Case of 12 Part #1685517.

SAE SW 30 SF/CD Cold Weather Engine Oil for use in all four cycle and diesel engines at 30° temp. and under. Case of 12 Quarts, Part # 1685576.

SAE 15W40 SF/CD Engine Oil for gas and diesel engines, warm weather; see engine manufacturer recommendations. Case of 12 Quarts, Part #1685554.

Grease Gun Kit has 12" flexible hose to get into tight spots with ease. Kit contains: gun and 1-8 oz. tube of grease, Part #1685510. For replacement tube, order Part # 103077.

Pneumatic Tire Seal, seals all leaks including bead leaks and punctures up to 3/16 inch diameters. Prevents flats for tread life of tire. Available in following amounts.

Case of 12 - 11 Oz. Tubes 1685537
Case of 24 - 11 Oz. Tubes 1685525
5 Gallon Pail 1685527

Touch-Up Paint keeps equipment in showroom condition.

Spray Cans	Quarts	Daubbers 12/Ctn.
*Simplicity Orange - 103262 (12 cans/1685179)	1685037	1685520 - Mixed (6 Simp. Orange, 6 White)
**Classic Orange - 1685558 (12 cans/1685559)	1685560	1685562 - Mixed (6 Classic Orange, 6-White)
White 103049 (12 cans/1685178)	1685032	1685562 - Mixed (6-Classic Orange, 6-White) 1685520 - Mixed (6-Simp. Orange, 6-White)
Black - 1685551 (12 Cans/1685552)	N.A.	N.A.

*For 1977 thru early 1985 products.
**For products produced after 12/1/85.

Simplicity Designer Seat Covers are double stitched, easy care vinyl. Keeps new seats new, makes worn seats look new.

- Small Cover for 4000, 5000,
& 6100 Tractors 1685540
- Large Cover for 6200, 7000 &
9000 Tractors 1685541
- SunStar Seat Cover 1685577

Extend Equipment Life - Use Only Genuine Simplicity Parts

Table of Contents

	Page
FRAME & STEERING GROUP Frame, Steering Wheel, Column, Cables, Rear Platform	4
REAR AXLE & REAR WHEELS GROUP Rear Axle, Spindles, Steering Arms, Rear Wheels	8
ENGINE GROUP Engine, Drive Pulley, Belt Guides, Muffler, Shields	10
TRANSMISSION GROUP Transmission, Support, Chain Guard, Shift Arm, Clutch Arm, Pulleys	12
FUEL SYSTEM GROUP Fuel Tanks, Fuel Lines & Connectors	14
DIFFERENTIAL & FRONT WHEELS GROUP Axe Assembly, Brake Drum, Front Wheels	16
BRAKE & CLUTCH GROUP Pedal, Clutch Rod, Brake Rod, Brake Band	18





Table of Contents - Continued**Page****PTO & MOWER LIFT GROUP**


Lift Lever, PTO Levers & Rod,
Cable Assy. & Pulleys

20

**SEAT & DECK GROUP**


(Mfg. Nos. 1691330 & 1691198)
Seat, Deck, Hinges,
Latches

22

**SEAT & DECK GROUP**

(Mfg. Nos. 1691457 & 1691458)
Seat, Deck, Hinges,
Latches

24

**CONSOLE & CONTROL GROUP**


Steering Column Housing, Console, Throttle
Cables, Shift Cable, Handles & Levers

28

**ELECTRICAL GROUP**

(Mfg. Nos. 1691330 & 1691198)
Wiring Harness, Safety Switch, Battery, Solenoid,
Micro Circuits, Circuit Breaker, Ignition Switch

30

**ELECTRICAL GROUP**

(Mfg. Nos. 1691457 & 1691458)
Wiring Harness, Safety Switch, Battery, Solenoid,
Micro Circuits, Circuit Breaker, Ignition Switch

32



**42" MOWER DECK & ARBOR GROUP**

Deck, Belt Covers, Deflectors, Baffles,
Guard, Arbors & Blades


34



Table of Contents - Continued**Page**

42" MOWER DRIVE GROUP Pulleys, Belt, Mower Rod, Brake Rod		36
42" MOWER SUPPORT GROUP Support Arm Assembly, Yoke, Wheels, Spindles		38
36" MOWER DECK & ARBOR GROUP Deck, Belt Covers, Deflector, Baffle, Arbors & Blades, Shield, Housing		40
36" MOWER BAFFLE & GAUGE ROLLER GROUP Baffle, Rollers, Brackets		42
36" MOWER DRIVE GROUP Pulleys, Belt, Mower Rod, Brake Rod		44
36" MOWER SUPPORT GROUP Support Arm Assembly, Yoke, Wheels, Spindles		46
DECAL & PAINT GROUP		48
TRANSMISSION - Peerless Parts Breakdown		50
DIFFERENTIAL - Peerless Parts Breakdown		52

A-77-1495



NOTE: Use standard hardware torque spec. chart unless otherwise noted.


Ref. No.	Part No.	Qty.	Description
1	1678367	1	PLATFORM
2	1678389	1	ROD, Latch, Platform
3	1678390	1	SPRING, Torsion, Latch Rod
4	1931833	4	BOLT, Carriage, 5/16-18 x 3/4
5	1678368	1	BRACKET, Pivot, Platform
6	108717	2	SPACER, Pivot Bracket
7	1923683	2	CAPSCREW, Taptite, 3/8-16 x 3/4
8	1917372	4	NUT, Hex, 5/16-18
9	1917356	4	LOCKWASHER, 5/16
10	1664004	2	CLIP, Latch Rod
11		2	WEIGHT, Rear (Order Mfg. No. 1691293 thru Wholegoods)
12	1657017	1	CAP, Steering Wheel
13	1664847	2	SCREW, Taptite, 5/16-18 x 3/4
14	1678377	2	CLEVIS, Steering Cable
15	1916622	6	NUT, Hex, 1/4-20
16	925094	4	TIE, Steering Cable Boot, Self-locking
17	1700048	2	BOOT, Rubber, Steering Cable
18	1701151	2	CABLE, Steering
19	1923341	2	CAPSCREW, 1/4-20 x 3/4
20	1933979	2	CLAMP, Steering Cable
21	1916964	2	LOCKWASHER, 1/4
22	1678380	4	SCREW, Special, Fuel Tank
23	1924856	4	SCREW, Taptite, 5/16-18 x 1/2
24	1678449	2	SUPPORT ASSY., Fuel Tank
25	1678424	2	RETAINER, Steering Cable
26	1664847	2	CAPSCREW, Taptite, 5/16-18 x 3/4
27	1930648	1	LOCKNUT, 1/2-13
28	1924361	1	WASHER, 1/2
29	1678244	1	DRUM, Steering Shaft
30	1764440	3	BUSHING, Nylon, Steering Shaft
31	1685361	1	FRAME ASSY.
32	921133	1	FITTING, Lube
33	1678310	1	STEERING SHAFT ASSY.
34	1678381	1	TUBE, Cover, Steering Shaft
35	1925690	1	CAPSCREW, 5/16-18 x 3-1/2
36	1919326	2	WASHER, 5/16
37	1923362	1	NUT, 5/16-18 Centerlock
38	1670969	1	STEERING WHEEL

***Early Models**

Used on Mfg. No. 1691457 before Serial No. 001557

Used on Mfg. No. 1691458 before Serial No. 001811

NOTE: Newer models frames have bearings for steering shaft (no bushings, grease fittings, or tube in frame for steering shaft).



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1678367	1	PLATFORM
2	1678389	1	ROD, Latch, Platform
3	1678390	1	SPRING, Torsion, Latch Rod
4	1931333	4	BOLT, Carriage, 5/16-18 x 3/4
5	1678368	1	BRACKET, Pivot, Platform
6	108717	2	SPACER, Pivot Bracket
7	1923683	2	CAPSCREW, Taptite, 3/8-16 x 3/4
8	1917372	8	NUT, Hex, 5/16-18
9	1917356	8	LOCKWASHER, 5/16
10	1664004	2	CLIP, Latch Rod
11		2	WEIGHT, Rear (Order Mfg. No. 1691293 thru Wholegoods)
12	1657017	1	CAP, Steering Wheel
13	1664847	4	SCREW, Taptite, 5/16-18 x 3/4
14	1678377	2	CLEVIS, Steering Cable
15	1916622	6	NUT, Hex, 1/4-20
16	925094	4	TIE, Steering Cable Boot, Self-locking
17	1700048	2	BOOT, Rubber, Steering Cable
18	1701151	2	CABLE, Steering
19	1921960	2	CAPSCREW, 1/4-20 x 1
20	1701700	2	CLAMP, Steering Cable
21	1916964	2	LOCKWASHER, 1/4
22	1678380	4	SCREW, Special, Fuel Tank
23	1924856	4	SCREW, Taptite, 5/16-18 x 1/2
24	1678449	2	SUPPORT ASSY., Fuel Tank
25	1678424	1	RETAINER, Steering Cable
26	1931333	4	CARRIAGE BOLT, 5/16-18 x 3/4
27	1960355	1	NUT, ESNA, Heavy Lock, 1/2-13
28	1924361	1	WASHER, 1/2
29	1678244	1	DRUM, Steering Shaft
30	1702385	2	BEARING, Flange
31	1685361	1	FRAME ASSY.
32	172436	2	CLIP, Cable
33	1702704	1	STEERING SHAFT ASSY.
34	1678381	1	TUBE, Cover, Steering Shaft
35	1925690	1	CAPSCREW, 5/16-18 x 3-1/2
36	1919326	2	WASHER, 5/16
37	1923362	1	NUT, 5/16-18 Centerlock
38	1670989	1	STEERING WHEEL
39	1702195	1	SPACER


*Later Models

Used on Mfg. No. 1691457 after Serial No. 001556

Used on Mfg. No. 1691458 after Serial No. 001810

See Frame Group.


A-**1496



Ref. No.	Part No.	Qty.	Description
1	1926158	1	CAPSCREW, 1/2-13 x 4
2	930672	2	KEY, Hi-Pro, 3/16 x 5/8
3	1928804	2	SETSCREW, Sq. Hd., 1/4-20 x 3/8
4	1677915	2	STEERING ARM ASSY., Upper
5	1960261	2	PIN, Steering Arm
6	1918445	2	COTTER PIN, 1/2
7	176440	10	BUSHING, Nylon
8	1678228	1	TUBE, Pivot Support
9	921133	5	FITTING, Lube
10	927794	2	E-RING, Retaining
11	1920415	6	CAPSCREW, Hex, 3/8-16 x 1-1/4
12	1677914	1	SPINDLE ASSY., L.H.
13	1672269	2	TIRE, Turf, 4.10/3.50-4 (Carlisle)
14	159141	2	TUBE, 4.10/3.50-4 (Service Only) (See note below.)
15	172353	2	VALVE STEM & CAP
16	1679712	2	WHEEL ASSY. (Incl. Ref. No. 17)
17	1679713	4	BEARING, Wheel
18	960202	2	WASHER, Wheel
19	927794	2	E-RING, Retaining, Wheel
20	1679698	2	WHEEL & TIRE ASSY., 4.10/3.50-4
21	1678333	6	SPACER
22	1924940	4	WASHER, 3/8
23	1930651	6	LOCKNUT, 3/8-16
24	1678313	2	TIE ROD
25	1677918	1	STEERING ARM ASSY., L.H. (Shown)
	1677919	1	STEERING ARM ASSY., R.H. (Not Shown)
26	1678072	1	DRAG LINK
27	1677911	1	SPINDLE ASSY., R.H.
28	1916951	1	NUT, 1/2-13
29	1916966	1	LOCKWASHER, 1/2
30	1677905	1	REAR AXLE ASSY.
31	1673333	2	CAP, Threaded

NOTE: Simplicity Tire Sealant can be used to repair tires in place of tubes. See inside front cover of this manual for part number.


A-**1497



Ref. No.	Part No.	Qty.	Description
1		*1	ENGINE, 12 HP (Briggs & Stratton) (Includes muffler)
		*1	ENGINE, 8 HP (Briggs & Stratton) (Includes muffler)
		**1	ENGINE, 12 HP (Tecumseh) (Includes muffler)
2	1930591	2	SCREW, Whizlock, 5/16-18 x 3/4 (12 HP only)
	1960295	2	SCREW, Whizlock, 1/4-20 x 5/8 (8 HP only)
3	1655880	1	PIPE, Exhaust (12 HP Briggs & Stratton only)
	1700455	1	PIPE, Exhaust (8 HP Briggs & Stratton only)
4	1650670	1	GASKET, Muffler (12 HP Briggs & Stratton only)
	1700456	1	GASKET, Muffler (8 HP Briggs & Stratton only)
5	1923382	1	LOCKNUT, 5/16-18
6	1700396	1	SHIELD, Heat (Muffler)
7	1917372	3	NUT, Hex, 5/16-18
8	1917642	1	WASHER, Plain, 5/16
9	1676183	1	CLAMP
10	1931342	1	BOLT, Carriage, 5/16-18 x 2-3/4
11	1917356	2	LOCKWASHER, 5/16
12	1927429	4	SCREW, Taptite, 1/4-20 x 5/8
13	1700164	1	BRACKET, Muffler
14	1924856	2	SCREW, Taptite, 5/16-18 x 1/2
15	1700232	1	HEAT SHIELD ASSY. (Briggs & Stratton only)
	1679891	1	HEAT SHIELD ASSY. (Tecumseh only)
16	1667346	1	CAP, Hex, 3/8
17	1664989	1	DRAIN, Oil
18	1932849	1	LOCKNUT, Conduit, 3/8
19	1678306	1	STOP, Belt
20	1924940	3	WASHER, 3/8
21	930598	4	SCREW, Taptite, 3/8-16 x 1-1/2
22	1920353	1	CAPSCREW, Hex, 7/16-20 x 1-1/2 (Briggs engines only)
	1922128	1	CAPSCREW, Hex, 3/8-24 x 1-1/2 (Tecumseh engines only)
23	1918199	1	LOCKWASHER, 7/16 (Briggs engines only)
	1916965	1	LOCKWASHER, 3/8 (Tecumseh engines only)
24	1933263	1	WASHER, 3/8
25	1678163	1	PULLEY ASSY., Engine
26	1678354	1	BELT, Transmission Drive
27	1666804	1	SPACER
28	1678435	1	STOP, Belt
29	172844	1	STOP, Belt

*See your local Briggs & Stratton distributor for engine parts & service.

**See your local Tecumseh distributor for engine parts & service, including
muffler, gasket, hardware, etc.




NOTE: Use standard hardware torque spec. chart unless otherwise noted.

Assemble master link with closed end of clip facing in the direction of forward chain movement. With Ref. No. 9 (carriage bolt) loose, rotate axle sprocket counterclockwise while holding Ref. No. 15 (nylon roller) against the chain until the farthest forward position of the roller is located. At this point, hold the nylon roller firmly against the chain while tightening Ref. No. 9 (carriage bolt).

Ref. No.	Part No.	Qty.	Description
1	1930601	2	SCREW, Taptite, 5/16-18 x 5/8
2	1678285	1	BRACKET, Cable
3	1922234	1	CAPSCREW, Hex, 1/4-28 x 5/8
4	1916964	1	LOCKWASHER, 1/4
5	1919381	1	WASHER, 5/16
6	1678283	1	LEVER, Shift
7	1924856	2	SCREW, Taptite, 5/16-18 x 1/2
8	1678372	1	GUARD, Chain
9	1960315	1	CARRIAGE BOLT, 3/8-16 x 2.0
10	1677867	1	SUPPORT, Transmission
11	1927429	2	SCREW, Taptite, 1/4-20 x 5/8
12	1664847	2	SCREW, Taptite, 5/16-18 x 1/2
13	1922611	2	WASHER, 3/8
14	170369	1	SPACER
15	170177	1	ROLLER, Nylon
16	1930651	1	NUT, Hex Jam Lock, 3/8-16
17	1676351	1	SPRING
18	1921971	1	CAPSCREW, 3/8-16 x 1-3/4
19	1668827	1	PULLEY, Idler
20	1656054	1	STOP, Belt
21	1930645	1	NUT, Flange Lock, 3/8-16
22	1922130	1	CAPSCREW, 3/8-16 x 2-1/4
23	1924940	1	WASHER, 3/8
24	1916803	1	LOCKWASHER, 3/8
25	1678054	1	CLUTCH ARM ASSY.
26	1678057	1	SPACER
27	927103	1	RING, Retaining
28	1678350	1	PULLEY ASSY., Transmission
29	905123	1	KEY, Woodruff No. 9
30	1930591	2	SCREW, Hex Whizlock, 5/16-18 x 3/4
*31		1	TRANSMISSION, 5 Speed
32	1927477	2	SCREW, Taptite, 5/16-18 x 1
33	1917642	2	WASHER, Plain, 5/16
34	172845	2	STOP, Belt


*Refer to page 50 for parts breakdown. See your local Tecumseh/Peerless distributor for parts and service.

A-**1499



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1702507	2	CAP, Fuel Tank (Later models 2-3/8" O.D.)
	1678454	2	CAP, Fuel Tank (Earlier Models 1-13/16" O.D.)
2	1702509	1	TANK, Fuel (R.H.) (Incl. Cap Part No. 1702507)
3	1702508	1	TANK, Fuel (L.H.) (Incl. Cap Part No. 1702507)
4	1960112	9	CLAMP, Hose
5	1676861	2	HOSE, Fuel, 45-1/2" (cut to length)
6	1678455	2	VALVE, Shutoff
7	1650793	2	GROMMET
8	1678320	1	FITTING, Tee



NOTE A: Left wheel to be installed first with end play taken out to left. Install right wheel and add washer(s) (Ref. No. 23) as required to remove end play.)



NOTE: Use standard hardware torque spec. chart unless otherwise noted.

NOTE: See Chain Assy. & Adjustment note on page 10.


Ref. No.	Part No.	Qty.	Description
*1		1	AXLE ASSY., Differential
2	1678376	1	CHAIN, Roller
3	1668296	1	SPROCKET, 54 Tooth
4	1678408	1	SHIM, Sprocket
5	1668295	1	DRUM, Brake
6	1935048	4	NUT, Flange Lock, 5/16-18
7	1701772	1	SPACER, Axle
8	108202	2	BEARING
9	1665696	2	FLANGE, Bearing
10	1924856	5	SCREW, Taptite, 5/16-18 x 1/2
11	1925359	1	SCREW, Taptite, 5/16-18 x 3/4
12	1678447	1	STOP, Brake Band
13	927794	2	RING, Retaining, Wheel
14	960202	3	WASHER, 3/4
15	8221042	2	KEY, 3/16 x 3/16 x 1-1/2
16	1701322	2	WHEEL ASSY.
17	1664090	2	TUBE (Service Only) (See note below.)
18	172353	2	VALVE STEM & CAP
19	1700099	2	TIRE, 15 x 6.00-6
20	1701321	2	WHEEL & TIRE ASSY., 15 x 6.00-6
21	1701112	1	MASTER LINK, Chain
22	1673333	2	CAP, Threaded
23	1960114	3	WASHER, Shim, 3/4 x 1-1/16 (Use as needed)

*See page 52 for parts breakdown. For parts & service see your local Tecumseh/Peerless distributor.

NOTE: Simplicity Tire Sealant can be used to repair tires in place of tubes. See inside front cover of this manual for part number.




Ref. No.	Part No.	Qty.	Description
1	1923362	3	NUT, Hex Lock, 5/16-18
2	157041	1	SPRING
3	164094	1	GUIDE ASSY., Rod
4	1678287	1	ROD, Clutch
5	1919326	1	WASHER, 11/32 x 3/4
6	1918447	2	PIN, Cotter, 3/4
7	1960286	1	CAPSCREW, 1/2-13 x 3-1/2, Gr. 5
8	1667132	2	PIN
9	1679357	1	BAND ASSY., Brake
10	1678409	1	SPACER
11	1678279	1	LINK, Brake Arm
12	1917378	1	WASHER, 3/8
13	1678284	1	ROD, Brake
14	1700114	1	GUIDE ASSY., Rod
15	1919439	1	NUT, Hex Lock, 3/8-16
16	1676435	1	WASHER, 1/2
17	1916966	1	LOCKWASHER, 1/2
18	1916951	1	NUT, Hex, 1/2-13
19	1678327	2	BRACKET, Brake
20	1924856	5	SCREW, Taptite, 5/16-18 x 1/2
21	1678326	1	SHAFT ASSY., Brake
22	1678328	1	SPACER
23	1960260	1	NUT, Push
24	1678341	1	SPRING
25	1666664	1	PAD, Pedal
26	1665844	1	SPACER
27	1678340	1	LATCH, Brake



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1665835	2	GRIP
2	1678255	1	LEVER ASSY., Lift
3	1928804	2	SET SCREW, 1/4-20 x 3/8
4	918312	1	KEY, 3/16 x 5/8
5	1678258	1	LEVER ASSY.
6	1917377	2	WASHER, 1/4
7	1960221	1	PIN, Quick
8	1678400	1	LEVER, PTO
9	1918447	2	PIN, Cotter, 3/4
10	1917642	2	WASHER, 5/16
11	1678401	1	SPACER
12	1678402	1	LEVER ASSY., PTO
13	1678404	1	LEVER, PTO
14	928637	1	KEY, Hi-Pro, 5/32 x 5/8
15	1678330	1	ROD, PTO
16	1923358	2	NUT, Hex, Lock, 1/4-20
17	1678448	1	GUIDE, Cable
18	1678335	2	PULLEY, Lift Cable
19	1678392	2	SPACER
20	1960151	3	WASHER, 1/4
21	1921960	1	CAPSCREW, 1/4-20 x 1.0
22	1917372	1	NUT, Hex, 5/16-18
23	1917356	1	LOCKWASHER, 5/16
24	1678263	1	BRACKET, Pulley
25	1931320	1	CARRIAGE BOLT, 1/4-20 x 1-1/4
26	1960282	1	CARRIAGE BOLT, 5/16-18 x 3/4
27	1678334	1	CABLE ASSY., Lift


A-**1503



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1700618	1	SEAT (Used on 1691330 and on 1691198 after serial no. 1089.)
	1676538	1	SEAT (Used on 1691198 before serial no. 1070.)
2	1921332	12	CAPSCREW, 5/16-18 x 3/4
3	1919381	2	WASHER
4	1678415	4	HINGE, Seat Deck
5	1917356	12	LOCKWASHER, 5/16
6	1917372	12	NUT, Hex, 5/16-18
7	932724	2	RING, Retaining
8	1924856	2	SCREW, Taptite, 5/16-18 x 1/2
9	1678416	2	SPRING, Latch
10	1930642	1	NUT, Flange, Lock, 1/4-20
11	1679941	1	ROD, Deck Latch
12	1678417	2	LATCH, Seat, Pull Tight
13	1675044	4	RIVET, Seat Latch
14	1678361	1	DECK, Seat
15	1917642	8	WASHER, Flat, 5/16
16	1923701	2	CAPSCREW, 3/8-16 x 2
17	1930651	2	NUT, Hex Lock, 3/8-16
18	1666200	2	HINGE, Upper, Seat
19	1666690	2	SPRING, Seat
20	1666691	2	COVER, Spring


A-1503



NOTE: Use standard hardware torque spec. chart unless otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1700618	1	SEAT
2	1921332	12	CAPSCREW, 5/16-18 x 3/4
3	1923358	2	NUT, Hex Centerlock, 1/4-20
4	1678415	4	HINGE, Seat Deck
5	1917356	12	LOCKWASHER, 5/16
6	1917372	8	NUT, Hex, 5/16-18
7	932724	2	RING, Retaining
8	1924856	2	SCREW, Taprite, 5/16-18 x 1/2
9	1678416	2	SPRING, Latch
10	1917377	1	WASHER, 1/4 x 3/4
11	1960151	2	WASHER, 1/4 x 1-1/4
12	1678417	2	LATCH, Seat, Pull Tight
13	1675044	4	RIVET, Seat Latch
14	1701405	1	DECK, Seat
15	1917642	12	WASHER, Flat, 5/16
16	1923701	2	CAPSCREW, 3/8-16 x 2
17	1930651	2	NUT, Hex Lock, 3/8-16
18	1666200	2	HINGE, Upper, Seat
19	1666690	2	SPRING, Seat
20	1666691	2	COVER, Spring
21	1701280	1	ROD, Seat Deck
22	1921960	1	CAPSCREW, Hex, 1/4-20 x 1


A-**1503




NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1700618	1	SEAT
2	1921332	12	CAPSCREW, 5/16-18 x 3/4
3	1923358	2	NUT, Hex Centerlock, 1/4-20
4	1678415	2	HINGE, Seat Deck
5	1917356	12	LOCKWASHER, 5/16
6	1917372	8	NUT, Hex, 5/16-18
7	932724	2	RING, Retaining
8	1924856	2	SCREW, Taptite, 5/16-18 x 1/2
9	1702722	2	SPRING, Latch
10	1917377	1	WASHER, 1/4 x 3/4
11	1960151	2	WASHER, 1/4 x 1-1/4
12	1678417	2	LATCH, Seat, Pull Tight
13	1675044	4	RIVET, Seat Latch
14	1701405	1	DECK, Seat
15	1917642	12	WASHER, Flat, 5/16
16	1923701	2	CAPSCREW, 3/8-16 x 2
17	1930651	2	NUT, Hex Lock, 3/8-16
18	1701559	2	HINGE, Upper, Seat
19	1666690	2	SPRING, Seat
20	1666691	2	COVER, Spring
21	1701280	1	ROD, Seat Deck
22	1921960	1	CAPSCREW, Hex, 1/4-20 x 1
23	1921333	1	CAPSCREW, Hex, 5/16-18 x 1
24	1702158	1	MOULDING, Deck
25	1701509	1	LATCH, Seat
26	1701560	2	HINGE, Lower
27	1960282	4	BOLT, Carriage, 5/16-18 x 3/4

Transmission MUST remain in neutral when shift lever (Ref. No. 2) is against upper & lower neutral stops of steering column console (Ref. No. 36).



Ref. No.	Part No.	Qty.	Description
1	1678365	2	KNOB, Control
2	1701278	1	ROD ASSY., Shift (1691457 & 1691458)
	1678427	1	ROD ASSY., Shift (1691198 & 1691330)
3	1924433	2	NUT, Hex, Fiber Lock, 5/16-18
4	1665889	1	SPACER
5	1685327	1	PIVOT, Shift (Incl. Ref. No. 38)
6	1678425	1	SPACER
7	1678429	1	SPRING, Torsion
8	1917642	1	WASHER, Flat, 5/16
9	1922127	1	CAPSCREW, Hex, 5/16-18 x 1-3/4
10	1917458	1	WASHER, #6, Plain
11	1678360	2	WASHER, Nylon, 33/64 x 1
12	1960221	2	PIN, Quick
13	1678283	1	LEVER, Shift
14	1960261	2	PIN
15	1678377	2	CLEVIS
16	1678436	2	NUTS, Special #10-32
17	1700860	2	NUT, Collar
18	1678288	1	CABLE, Transmission
19	1678362	1	THROTTLE ARM
20	1917377	2	WASHER, 1/4
21	1923358	1	LOCKNUT, 1/4-20
22	1678371	1	CABLE, Throttle
23	1930531	1	SCREW, Rd. Hd., #10-32 x 1/2
24	1922711	1	LOCKWASHER, Ext. Tooth #10
25	158475	1	CLIP, Throttle Cable
26	1923212	1	WASHER, 7/32 x 1/2
27	1928919	1	NUT, #10-32
28	1678366	2	WASHER, Nylon, 17/64 x 3/4 x 7/8
29	1921960	1	CARRIAGE BOLT, 1/4-20 x 1
30	1678245	1	PANEL, Steering Column
31	1676860	6	SCREW, Hex, Type AB
32	1678437	2	MAT, Foot
33	1676647	5	SPEED NUT, "U" Type
34	1924856	4	SCREW, Taptite, 5/16-18 x 1/2
35	1685362	1	COLUMN ASSY., Steering
36	1678357	1	CONSOLE, Steering Column
37	1678419	4	SCREW, Taptite, 1/4-20 x 3/4
38	1700880	1	SPACER (Shift Lever)
39	1701274	1	NEUTRAL SWITCH ARM (1691457 & 1691458 only)
40	1930947	1	LOCKWASHER, #5 Spring (1691457 & 1691458 only)
41	1701328	1	FLIPPER, Switch (1691457 & 1691458 only)
42	1701275	1	BRACKET, Switch (1691457 & 1691458 only)
43	1930416	2	SCREW, Taptite #10-32 x 3/8 (1691457 & 1691458 only)
44	1935944	1	SCREW, Taptite, #5-40 x 3/4 (1691457 & 1691458 only)
45	1920397	1	NUT, Hex Lock (ESNA) 1/4-20 (1691457 & 1691458 only)
46	1917458	1	WASHER, #6, Plain (1691457 & 1691458 only)




NOTE: Use standard hardware torque spec. chart unless otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	930222	3	CLIP, Wire
2	172436	1	CLIP, Wire
3	1700636	1	SWITCH, Seat (Used on all 1691330 and 1691198 after serial no. 1069.)
	1671703	1	SWITCH, Seat (Used on 1691198 before serial no. 1070.)
4	1921880	2	LOCKWASHER, Ext., 1/4
5	1926025	2	SCREW, Rd. Hd., 1/4-20 x 1/2
6	926918	1	CLAMP, Wire
7	1931003	4	NUT, Hex, #5-40
8	1930947	4	LOCKWASHER, #6
9	1917458	4	WASHER, #6
10	1679932	2	MICRO SWITCH, Tandem
11	1923358	2	LOCKNUT, Hex, 1/4-20
12	1917377	2	WASHER, 1/4
13	1678398	2	STUD, Switch, Mtg.
14	122023	1	COVER, Terminal
15	1668819	1	CABLE ASSY., (Starter)
16	1672654	1	MODULE, DSI, Interlock (Used with Briggs & Stratton engine only.)
	1700195	1	MODULE, DSI, Interlock (Used with Tecumseh engine only.)
17	925592	2	SCREW, Taptite, 1/4-20 x 3/4, Pltd.
18	920263	2	NUT, Hex, 5/16-24
19	917356	2	LOCKWASHER, 5/16
20	1665238	1	CIRCUIT BREAKER
21	1700751	1	SOLENOID
22	1677297	1	CABLE ASSY. (Battery - Solenoid)
23	1671158	1	CABLE ASSY., (Battery Ground)
24	923341	2	CAPSCREW, Hex, 1/4-20 x 3/4
25	917377	2	WASHER, 1/4
26	916964	2	LOCKWASHER, 1/4
27	916622	2	NUT, Hex, 1/4-20
28	1685215	1	BATTERY, 12V
29	924856	1	SCREW, Taptite, 5/16 x 1/2
30	1678391	1	PAD, Foam, Battery
31	1665872	1	STRAP, Battery
32	1667805	1	BRACE, Battery
33	1960014	2	SCREW, Rnd. Hd., #5-40 x 1-1/2
34	932747	2	CABLE TY-WRAP
35	1676130	2	LAMP, Indicator
36	178280	1	SWITCH, Ignition (Incl. Ref. Nos. 37, 38 & 39)
37	918906	1	LOCKWASHER, Int. 5/8
38	122234	1	NUT, 5/8-32
39	122203	1	KEYS, & RING
*40	1700686	1	WIRING HARNESS

*Used on all 1691330 and on 1691198 after serial no. 1069. Mfg. No. 1691198 before serial no. 1070 requires alterations: cut seat switch connector off old wiring harness and replace the similar end on new harness with old connector.

A-** 1505



See Console & Controls Group

After Installation, key switch must not engage starter in "START" position with transmission in gear or PTO lever engaged or both.


Route through hole
in frame and up
through inside of
steering column.

This diagram shows a transmission switch assembly. The assembly includes a housing with a switch mechanism (31) and a mounting bracket (33). Various wires and components are labeled with numbers: 25, 26, 27, 28, 29, 31, 32, 33, 34, and 35. Callout 25 points to the transmission switch itself. Callout 26 points to a fastener. Callout 27 points to a wire. Callout 28 points to another wire. Callout 29 points to a third wire. Callout 31 points to the switch mechanism. Callout 32 points to a wire. Callout 33 points to the mounting bracket. Callout 34 points to a fastener. Callout 35 points to a wire.

Transmission Switch

Fasten wiring harness to steering cable beneath footrest, 2 places.


Mower PTO
Switch



NOTE: Use standard hardware torque spec. chart unless otherwise noted.


Ref. No.	Part No.	Qty.	Description
1	930222	3	CLIP, Wire
2	172436	3	CLIP, Wire
3	1700636	1	SWITCH, Seat
4	1921880	2	LOCKWASHER, Ext., 1/4
5	1926025	2	SCREW, Rd. Hd., 1/4-20 x 1/2
6	926918	1	CLAMP, Wire
7	916622	2	NUT, Hex, 1/4-20
8	916964	2	LOCKWASHER, 1/4
9	917377	2	WASHER, 1/4
10	1671158	1	CABLE ASSY. (Battery Ground)
11	1665872	1	STRAP, Battery
12	1667805	1	BRACE, Battery Hold Down
13	924856	1	SCREW, Taptite, 5/16 x 1/2 (Zinc Pltd.)
14	1685215	1	BATTERY, 12V
15	923341	2	CAP SCREW, Hex, 1/4-20 x 3/4
16	122023	1	COVER, Terminal
17	1672654	1	MODULE, DST, Interlock
18	925592	2	SCREW, Taptite, 1/4-20 x 3/4, Pltd.
19	920263	2	NUT, Hex, 5/16-24
20	917356	2	LOCKWASHER, 5/16
21	1665238	1	CIRCUIT BREAKER
22	1668819	1	CABLE ASSY., Starter
23	1701526	1	CABLE ASSY., (Battery Solenoid)
24	1700751	1	SOLENOID
25	1931003	4	NUT, Hex, #5-40
26	1930947	4	LOCKWASHER, #5
27	1679932	2	MICRO SWITCH, Tandem
28	1917458	4	WASHER, #6
29	1960014	4	SCREW, Rnd. Hd., #5-40 x 1-1/2
30	932747	2	CABLE TY-WRAP
31	1676130	2	LAMP, Indicator
32	178280	1	SWITCH, Ignition (Incl. Ref. Nos. 33, 34 & 35.)
33	918906	1	LOCKWASHER, Int. 5/8
34	122234	1	NUT, 5/8-32
35	122203	1	KEYS & RING
36	1701286	1	WIRING HARNESS

A-***1507




NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1678294	1	COVER ASSY., Belt, R.H.
2	1917421	1	NUT, Hex, Jam, 3/8-16
3	1922611	2	WASHER
4	1917372	5	NUT, 5/16-18
5	1917356	5	LOCKWASHER, 5/16
6	1917378	5	WASHER, 3/8
7	1927428	1	SCREW, Taptite, 1/4-20 x 3/8
8	1924009	4	CAPSCREW, Hex, 1/4-20 x 7/8
9	1678295	1	COVER ASSY., Belt, L.H.
10	1936723	3	CAPSCREW, Hex, 7/16-14 x 1-3/4
11	1918199	3	LOCKWASHER, 7/16
12	1933263	3	WASHER, 7/16
13	1678271	3	PULLEY ASSY., Arbor
14	1657969	3	SHIELD, Bearing, Upper
15	1655729	3	HOUSING, Top (Arbor)
16	108202	6	BEARING
17	1685245	3	SHAFT, Arbor (Incl. Ref. No. 25)
18	1685251	3	SHAFT & BEARING ASSY. (Incl. Ref. Nos. 16 & 25)
19	1655728	3	HOUSING, Bottom (Arbor)
20	1927477	3	CAPSCREW, Taptite, 5/16-18 x 1
21	1664847	15	SCREW, Taptite, 5/16-18 x 3/4
22	1700230	3	WASHER, Shim
23	1657588	3	SHIELD, Grass
24	1655777	3	ADAPTOR, Blade
25	1672132	3	COLLAR, Mower Arbor
26	1656147	3	BLADE
27	1656927	3	WASHER, Spline
28	1656916	3	WASHER, Spring
29	1923491	3	CAPSCREW, Hex, 7/16-14 x 1
30	1916950	4	NUT, 3/8-16
31	1916965	4	LOCKWASHER, 3/8
32	1931348	4	BOLT, Carriage, 3/8-16 x 3/4
33	1608331	2	CLIP, Baffle
34	1916622	8	NUT, 1/4-20
35	1916964	8	LOCKWASHER
36	1917377	4	WASHER, 1/4
37	1608135	1	BAFFLE
38	1923333	4	CARRIAGE BOLT, 1/4-20 x 5/8
39	1665709	1	BAFFLE, Discharge
40	108186	2	CLIP, Baffle
41	1700841	2	PLUG, Plastic
42	1685307	1	HOUSING ASSY., 42" Mower
43	1919381	1	WASHER, 5/16
44	1931335	1	CARRIAGE BOLT, 5/16-18 x 1
45	1665562	1	GUARD, Mower Discharge
46	1931333	1	CARRIAGE BOLT, 5/16-18 x 3/4
47	1656049	1	DEFLECTOR



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.


Ref. No.	Part No.	Qty.	Description
1	1678241	1	BELT
2	1916950	4	NUT, Hex, 3/8-16
3	1916965	4	LOCKWASHER
4	1922611	2	WASHER
5	1676088	1	SPACER
6	1663114	2	BUSHING
7	1678238	1	ARM ASSY., Clutch
8	1917642	8	WASHER, 5/16
9	171247	3	PULLEY, Idler
10	1678305	1	STOP, Belt (Early Models)
	1701921	1	STOP, Belt (Later Models)
11	1666294	1	SPACER
12	1685150	1	PULLEY ASSY.
13	1922755	1	WASHER, 3/8
14	1677135	1	GUIDE, Belt
15	1928635	1	SCREW, Taptite, 3/8-16 x 1-1/4
16	1678236	1	ROD, PTO
17	1920161	2	NUT, Hex, Jam, 5/16-18
18	1678237	1	SPRING, PTO Rod
19	1657242	1	SPACER
20	1924356	2	WASHER
21	1678405	1	STOP, Belt
22	1700178	1	BRACKET, Brake
23	1917372	2	NUT, Hex, 5/16-18
24	1917356	2	LOCKWASHER, 5/16
25	1666294	2	SPACER
26	1664004	2	CLIP
27	1678353	1	ROD, Brake
28	1918196	1	PIN, Spring
29	1700129	1	ROD, Brake
30	1700869	1	SPRING
31	1960223	2	CARRIAGE BOLT, 5/16-18 x 1-1/4
32	1931333	6	CARRIAGE BOLT, 5/16-18 x 3/4
33	1960246	1	CAPSCREW, Hex, 3/8-16 x 4-1/2
34	1678412	2	BRACE
35	1678240	2	SUPPORT, Idler
36	1921971	3	CAPSCREW, Hex, 3/8-16 x 1-3/4
37	1927557	6	NUT, Flange Whizlock, 5/16-18



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.


Ref. No.	Part No.	Qty.	Description
1	1678247	1	ARM ASSY.
2	1960221	1	PIN, Quick
3	1921319	2	WASHER, 1/4
4	1960296	1	PIN, Lift Cable
5	1923341	1	CAPSCREW, Hex, 1/4-20 x 3/4
6	1918196	4	PIN, Quick
7	105249	2	PIN, Hitch
8	176012	2	PIN, Safety
9	1678291	2	SPACER, Rear
10	1678434	4	PIN
11	1929116	1	CAPSCREW, Hex, 3/8-16 x 2
12	1678339	1	BRACKET, Lift
13	1917356	1	LOCKWASHER, 5/16
14	1917372	1	NUT, Hex, 5/16-18
15	1678337	1	CHAIN, Lift
16	1921880	1	LOCKWASHER, Ext., 1/4
17	1916622	1	NUT, Hex, 1/4-20
18	1931333	1	CARRIAGE BOLT, 5/16-18 x 3/4
19	1960286	2	CAPSCREW, Hex, 1/2-13 x 3-1/2
20	1678304	2	SPACER, Wheel
21	1921133	4	FITTING, Lube, 1/4
22	1702483	2	WHEEL
23	1678092	2	YOKE ASSY., Wheel
24	1930644	2	NUT, Lock, 1/2-13
25	176440	4	BUSHING
26	927794	2	E-RING
27	1921974	3	CAPSCREW, Hex, 3/8-16 x 1-1/2
28	1678292	2	SPACER, Front
29	1917421	4	NUT, Hex, Jam, 3/8-16

A-1510



NOTE: Use standard hardware torque spec. chart unless otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1700398	1	COVER, Belt
2	1927428	4	SCREW, Taptite, 1/4-20 x 3/8
3	1936723	2	CAPSCREW, Hex, 7/16-14 x 3/4
4	1918199	2	LOCKWASHER
5	1933263	2	WASHER
6	1700271	2	PULLEY ASSY., Arbor
7	1657969	2	SHIELD, Upper Grass
8	1655729	2	HOUSING, Top
9	108202	4	BEARING
10	1685245	2	SHAFT (Incl. Ref. No. 23)
11	1655728	2	HOUSING, Bottom
12	1700399	2	BRACKET, Belt Cover
13	1917372	4	NUT, Hex, 5/16-18
14	1917356	4	LOCKWASHER, 5/16
15	1917642	8	WASHER, Plain, 3/8
16	1702190	1	DEFLECTOR
17	1685251	2	SHAFT & BEARING ASSY. (Incl. Ref. Nos. 9, 10 & 23.)
18	1922755	2	WASHER, Plain, 3/8
19	1664847	8	SCREW, Taptite, 5/16-18 x 5/8
20	1700230	2	WASHER
21	1657588	2	SHIELD, Lower Grass
22	1655777	2	ADAPTOR, Blade
23	1672132	2	COLLAR, Mower Arbor
24	1657589	2	BLADE
25	1656927	2	WASHER, Spline
26	1656916	2	WASHER, Spring
27	1923491	2	CAPSCREW, Hex, 7/16-14 x 1
28	1927477	4	SCREW, Taptite, 5/16-18 x 1
29	1931348	2	CARRIAGE BOLT, 3/8-16 x 3/4
30	1685320	1	HOUSING ASSY., 36" Mower (Incl. Decals)
31	1916965	2	LOCKWASHER, 3/8
32	1916950	2	NUT, Hex, 3/8-16




NOTE: Use standard hardware torque spec. chart unless otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1931334	5	BOLT, Carriage, 5/16-18 x 7/8
2	1960245	3	CAPSCREW, Hex, 1/2-13 x 3
3	1926192	3	WASHER, 9/16 x 1-1/4
4	1702189	3	SPACER
5	1702144	3	GAUGE, Roller
6	1702137	1	BRACKET, Roller, Right
7	1917356	6	LOCKWASHER, 5/16
8	1917372	6	NUT, Hex, 5/16-18
9	1916622	1	NUT, Hex, 1/4-20
10	1916964	1	LOCKWASHER, 1/4
11	1931317	1	BOLT, Carriage, 1/4-20 x 3/4
12	1677715	3	NUT, Flange, Centerlock, 1/2-13
13	1702138	1	BRACKET, Roller, Center
14	1702143	1	BRACKET, Roller, Left
15	1671577	1	BAFFLE
16	1668500	1	BRACKET, Mower to Baffle
17	1921332	1	CAPSCREW, Hex Hd., 5/16-18 x 3/4


NOTE: For early model SunRunners without gauge wheels, all above parts (except Ref. No. 15) can be ordered as a kit, part number 1685346.

A-1511



NOTE: Use standard hardware torque spec. chart unless otherwise noted.


Ref. No.	Part No.	Qty.	Description
1	1664644	1	BELT, Drive
2	1700444	1	GUIDE, Belt (Early Models)
	1701921	1	GUIDE, Belt (Later Models)
3	1916950	2	NUT, Hex, 3/8-16
4	1916965	2	LOCKWASHER, 3/8
5	1917642	3	WASHER, 3/8 x 7/8
6	171247	1	PULLEY, Idler, Mower
7	1685150	1	PULLEY, Idler, Engine
8	1922755	2	WASHER
9	1677135	1	GUIDE, Belt
10	1928635	1	SCREW, Taplite, 3/8-16 x 1-1/4
11	1924356	4	WASHER, 13/32 x 1-1/2
12	1663114	2	BUSHING
13	1678238	1	ARM ASSY., Clutch
14	1678405	1	STOP, Belt
15	1921971	1	CAPSCREW, Hex Hd., 3/8-16 x 1-3/4
16	1920161	2	NUT, Hex Jam, 5/16-18
17	1700445	1	SPACER
18	1678237	1	SPRING
19	1678236	1	ROD, Mower
20	1918196	1	CLIP, Hair Pin
21	1700332	1	ROD, Brake
22	1928698	2	NUT, Hex Centerlock Jam, 5/16-18
23	1918447	2	PIN, Cotter
24	1960103	2	WASHER, 3/8
25	1700178	1	BRACKET, Brake
26	1700717	1	ROD, Brake
27	1663956	2	SPACER
28	1664004	2	CLIP
29	1700869	1	SPRING
30	1960223	2	CARRIAGE BOLT, 5/16-18 x 1-1/4
31	1923903	1	CAPSCREW, Hex Hd., 3/8-16 x 3
32	1923341	1	CAPSCREW, 1/4-20 x 3/4
33	933988	2	NUT, Retainer, 5/16
34	1657242	1	SPACER
35	106186	1	CLIP
36	1916964	1	LOCKWASHER, 1/4
37	1916622	1	NUT, Hex, 1/4-18
38	1666294	1	SPACER



NOTE: Use standard hardware
torque spec. chart unless
otherwise noted.

Ref. No.	Part No.	Qty.	Description
1	1700251	1	SUPPORT ASSY., 36" Mower
2	1960221	1	PIN, Quick
3	1921319	1	WASHER, 1/4
4	1960298	1	PIN, Lift Cable
5	105249	2	PIN, Hitch
6	176012	2	PIN, Safety
7	1918196	4	PIN, Quick
8	1678291	2	SPACER, Rear
9	1678434	4	PIN
10	1921210	4	CAPSCREW, Hex Hd., 3/8-16 x 1
11	1921133	2	FITTING, Lube
12	1678304	2	SPACER, Wheel
13	1702483	2	WHEEL
14	1960286	2	CAPSCREW, Hex Hd., 1/2-13 x 3-1/2
15	1678092	2	YOKE ASSY.
16	1930644	2	LOCKNUT, 1/2-13
17	176440	4	BUSHING
18	927794	2	E-RING
19	1678292	2	SPACER, Front
20	1917421	4	NUT, Hex, Jam, 3/8-16


A-**1506



Ref. No.	Part No.	Qty.	Description
1	1678431	1	DECAL, Shift Pattern
2	1678430	1	DECAL, Instrument Panel
3	1678457	1	DECAL, Side, R.H. (1691198 & 1691330 only)
	1701578	1	DECAL, Side, R.H. (1691457 & 1691458 only)
4	1678458	1	DECAL, Side, L.H. (1691198 & 1691330 only)
	1701579	1	DECAL, Side, L.H. (1691457 & 1691458 only)
5	1702655	1	DECAL, Drive Belts
6	1700226	1	DECAL, Stability
7		1	I.D. PLATE (Not Serviced)
8	1678460	1	DECAL, Caution & Controls
9	1678463	1	DECAL, Model No. 12 HP
	1700461	1	DECAL, Model No. 8 HP
10	1678459	1	DECAL, Steering Column
11		1	I.D. PLATE (Not Serviced)
12	1676921	1	DECAL, Danger
13		1	DECAL, OPEI (Not Serviced)
14	1676922	1	DECAL, Danger
15	1664935	1	DECAL, Simplicity
Not Shown			
	1700805	1	DECAL, "No Riders" (Located on back upper right hand corner of seat deck.)


Touch-up Paint

Paint Color	Spray Cans	Quarts	Case of 12	Touch-Up Daubers	12/Carton
Classic Orange	1685558	1685560	1685559	1685562	6 Classic Orange
White	103049	1685032	1685178	Not Avail.	6 White
Black	1685551	Not Avail.	1685552	Not Avail.	



Ref. No.	Part No.	Qty.	Description
1	770061	1	CASE, Transmission
2	772083	1	COVER, Transmission
3	776232	1	SHAFT, Output
4	778121A	1	GEAR, Spur (20 teeth)
5	778122A	1	GEAR, Spur (22 teeth)
6	778123A	1	GEAR, Spur (25 teeth)
7	778124A	1	GEAR, Spur (30 teeth)
8	778125	1	GEAR, Spur (35 teeth)
9	784266	1	COLLAR, Shift
10	786083	1	SPROCKET, (18 teeth)
11	786082	1	SPROCKET, (9 teeth)
12	776134	1	SHAFT, Counter
13	778137A	1	GEAR, Bevel (42 teeth)
13A	778136	1	GEAR, Spur (15 teeth)
14	778126A	1	GEAR, Spur (20 teeth)
15	778127A	1	GEAR, Spur (25 teeth)
16	778128A	1	GEAR, Spur (28 teeth)
17	778129A	1	GEAR, Spur (30 teeth)
18	776199	1	SHAFT, Input
19	778113A	1	BEVEL PINION, Input
20	786047	1	SPROCKET (8 teeth)
27	780105A	4	BUSHING, Flanged
28	786081	1	CHAIN, Roller (No. 41 chain, 24 links)
29	780072	5	WASHER, Thrust
30	780086	2	BEARING, Needle
31	792072	1	RING, Retaining
32	792035	1	RING, Retaining
33	780109	1	WASHER
34	788040	1	RING, Retaining
35	784267	1	ROD & FORK ASSY., Shift
36	792073	4	SCREW, Flanged Hex Hd., Thread Forming, 1/4-20 x 1-1/4
37	792089A	2	KEY
40	792077	1	BALL, Steel, 5/16"
41	792078	1	SCREW, Set, 3/8-16 x 3/8
42	792079	1	SPRING
43	780108	5	WASHER, Thrust
44	792001	1	"O" RING
45	792074	1	PLUG

NOTE: Above listed parts must be ordered from your local Tecumseh/Peerless distributor. Service, warranty and parts for Peerless products are not handled by Simplicity.



Ref. No.	Part No.	Qty.	Description
1	774344	1	HOUSING, Differential Carrier (Incl. Ref. No. 13)
1A	774345	1	HOUSING, Differential Carrier (Incl. Ref. No. 13)
2	774704	1	AXLE (8-63/64" Long)
3	774705	1	AXLE (22-9/64" Long)
4	778221	2	GEAR, Bevel
5	778068	2	GEAR, Pinion
6	786040	1	PIN, Drive
7	780096	2	WASHER, Thrust
8	780001	2	WASHER
10	792018	2	RING, Snap
11	792044	4	SCREW, Flanged Hex Hd., 5/16-18 x 3-15/16
12	792042	4	NUT, Lock, 5/16-18
13	780077	2	BUSHING

NOTE: Above listed parts must be ordered from your local Tecumseh/Peerless distributor. Service, warranty and parts for Peerless products are not handled by Simplicity.

**TORQUE SPECIFICATIONS FOR
STANDARD MACHINE HARDWARE**
TOLERANCE $\pm 20\%$

SIZE	SAE GRADE #2 	SAE GRADE #5 	SAE GRADE #8 
8-32	19 In. Lbs.	30 In. Lbs.	41 In. Lbs.
8-36	20 "	31 "	43 "
10-24	27 "	43 "	60 "
10-32	31 "	49 "	68 "
1/4-20	66 "	8 Ft. Lbs	12 Ft. Lbs.
1/4-28	76 "	10 "	14 "
5/16-18	11 Ft. Lbs	17 "	25 "
5/16-24	12 "	19 "	25 "
3/8-16	20 "	30 "	45 "
3/8-24	23 "	35 "	50 "
7/16-14	30 "	50 "	70 "
7/16-20	35 "	55 "	80 "
1/2-13	50 "	75 "	110 "
1/2-20	55 "	90 "	120 "
9/16-12	65 "	110 "	150 "
9/16-18	75 "	120 "	170 "
5/8-11	90 "	150 "	220 "
5/8-18	100 "	180 "	240 "
3/4-10	160 "	260 "	386 "
3/4-16	180 "	300 "	420 "
7/8-9	140 "	400 "	600 "
7/8-14	155 "	440 "	660 "
1-8	220 "	580 "	900 "
1-12	240 "	640 "	1,000 "

NOTE:

1. These torque values are to be used for all *Simplicity* hardware excluding: locknuts, self-tapping screws, thread forming screws, sheet metal screws and socket head setscrews.
2. Recommended seating torque values for locknuts:
 - a. For prevailing torque locknuts - use 65% of grade 5 torques.
 - b. For flange whizlock nuts (and screws) - use 135% of grade 5 torques.
3. Unless otherwise noted on assembly drawings all torque values must meet this specification.

BOLT HEAD MARKING

S.A.E. GRADE:



Simplicity Manufacturing, Inc.
500 N. Spring Street
P.O. Box 997
Port Washington, WI 53074-0997

Copyright © 1989 Simplicity Manufacturing, Inc.

PRINTED IN U.S.A.